



COMPANION® 20 MULTIMEDIA SPEAKER SYSTEM

Owner's Guide | オーナーズガイド

Safety and Regulatory Information

Please read this owner's guide

Please take the time to follow the instructions in this owner's guide carefully. It will help you set up and operate your system properly and enjoy its advanced features. Please save this owner's guide for future reference.

WARNING: To reduce the risk of fire or electrical shock, do not expose the product to rain or moisture.

WARNING: Do not expose this apparatus to dripping or splashing, and do not place objects filled with liquids, such as vases, on or near the apparatus. As with any electronic products, use care not to spill liquids into any part of the system. Liquids can cause a failure and/or a fire hazard





The lightning flash with arrowhead symbol within an equilateral triangle alerts the user to the presence of uninsulated, dangerous voltage within the system enclosure that may be of sufficient magnitude to constitute a risk of electrical shock.



The exclamation point within an equilateral triangle, as marked on the system, is intended to alert the user to the presence of important operating and maintenance instructions in this owner's guide.

WARNING: Do not place any naked flame sources, such as lighted candles, on or near the apparatus.

SAFETY AND REGULATORY INFORMATION

CAUTION: Make no modifications to the system or accessories. Unauthorized alterations may compromise safety, regulatory compliance, and system performance.

CAUTION: Long-term exposure to loud music may cause hearing damage. It is best to avoid extreme volume when using headphones, especially for extended periods.

CAUTION: Use only the power supply provided with the speaker system.



This product conforms to all EU Directive requirements as applicable by law. The complete Declaration of Conformity can be found at www.Bose.com/static/compliance.

Names and Contents of Toxic or Hazardous Substances or Elements

	Toxic or Hazardous Substances and Elements						
Part Name	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent (CR(VI))	Polybrominated Biphenyl (PBB)	Polybrominated diphenylether (PBDE)	
PCBs	Х	0	0	0	0	0	
Metal parts	Х	0	0	0	0	0	
Plastic parts	0	0	0	0	0	0	
Speakers	X	0	0	0	0	0	
Cables	X	0	0	0	0	0	

O: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T 11363-2006.

X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T 11363-2006.

SAFETY AND REGULATORY INFORMATION

NOTES:

- The product label is located on the bottom of the product.
- The product is intended to be used only with the power supply provided.
- The product must be used indoors. It is neither designed nor tested for use outdoors, in recreational vehicles, or on boats.
- Where the mains plug or appliance coupler is used as the disconnect device, such disconnect device shall remain readily operable.

Additional safety information

See the additional instructions on the Important Safety Instructions sheet (North America only) enclosed in the shipping carton.

iPod is a trademark of Apple Inc., registered in the U.S. and other countries.

©2011 Bose Corporation. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission.

SAFETY AND REGULATORY INFORMATION

Information about products that generate electrical noise

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, this is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. Connect the
 equipment to an outlet on a different circuit than the one to which the receiver
 is connected.
- Consult the dealer or an experienced technician for help.

NOTE: Unauthorized modification of the system could void the user's authority to operate this equipment and may void the warranty.

This product complies with the Canadian ICES-003 Class B specifications.

For future reference

For convenience, enter the serial number (S/N located on the bottom of the right speaker) below and on the Customer Warranty card.

Serial number:	
Purchased on:	

We suggest that you keep your purchase receipt and the limited warranty with this guide.

CONTENTS

INTRODUCTION


Congratulations on your purchase of the Bose® Companion® 20 multimedia speaker system. With these high-quality speakers, you can enjoy:

- Full, natural sound from just two speakers whether sitting directly in front of your computer or across the room.
- Sleek, space-saving design that complements the look of your computer.
- A unique control pod that makes it easy to adjust or mute the volume and connect headphones and other audio devices.
- Exclusive TrueSpace® stereo digital signal processing that reproduces wide, natural sound from only two speakers, bringing more life to music, games and videos.
- Proprietary digital signal processing that delivers crisp, clear performance at all listening levels.
- Advanced port design and driver that produce powerful low note performance and room-filling sound.

SETTING UP


Unpacking

During unpacking, make sure that all parts shown are in the carton. If any part is missing or damaged, contact your Bose dealer. Save the carton and all packing materials for possible future use.



^{*}Correct for your region.

Positioning the speakers and control pod



The size and shape of these speakers make it easy to position them directly next to your computer. To provide an accurate sound stage, you should observe the following guidelines:

 Place the left and right speakers (left and right speakers are identified on each speaker back panel) an equal distance from

SETTING UP

the center of your computer monitor or screen. They should be between 18 and 32 inches apart.

- Avoid putting objects directly in front of the lower part of the speaker grilles. This area is where the speaker driver is located.
- Do not place the speakers too far behind your computer monitor or screen because that will block the sound.
- Place the control pod so it is within easy reach.
- Keep the front of the speakers even with, or slightly forward of, the front of the computer screen.


Connecting the cables

Use the four provided cables and the AC power cord to make the connections shown on page 13.

CAUTION: Do not plug in the AC power cord until all other connections are completed.

- 1. Insert one end of the audio in cable (a) into the Audio In connector on the back of the right speaker.
- Insert the other end of the cable into the Headphone or Speaker output connector (the labels and positions of these connectors vary) on your computer.
- 3. Insert the control pod cable (b) plug into the Control Pod connector on the right speaker.
- Insert the free end of the DC power cable (© into the DC Power connector on the right speaker.
- Insert the end of the left speaker cable (1) into the Left Speaker connector on the right speaker.
- Insert the small end of the AC power cord (a) into the power pack and then insert the large end into an AC (mains) outlet.

CONNECTING



Connecting an external music source

You can connect an iPod, mp3 player, or other music source to the control pod using a 3.5 mm plug (not supplied). The music source audio and computer audio are mixed and will both play at the same time.

To connect an external music source

Fully insert the 3.5 mm plug from the music source into the Audio In connector on the control pod. To avoid hearing both the computer and external music source, mute the computer audio.

Connecting headphones

Use headphones with a 3.5 mm plug. Fully insert the 3.5 mm plug into the headphone connector on the control pod. Connecting headphones to the Companion® 20 system mutes the sound from the speakers.



USING THE SPEAKER SYSTEM

Turning on the system

Touch the top of the control pod to turn the speaker system on. The power indicator illuminates. Touch the top of the control pod again to turn the system off. The power indicator extinguishes.



Controlling the volume

Rotate the volume control (top outer band) on the control pod clockwise to increase the volume; counterclockwise to decrease volume.

When your sound source has a volume control

- Rotate the Companion® 20 control pod volume control fully counterclockwise to decrease the volume to minimum (zero).
- 2. Adjust the volume on your sound source to *near* maximum. As you increase the volume, no sound is emitted from the Companion® 20 speakers, because they are set to minimum.

Note: You should never turn your sound source up to maximum volume, as this could cause the sound to distort. A volume setting of about 80% of maximum should be sufficient.

3. Rotate the Companion® 20 control pod volume control clockwise until the sound reaches the desired listening level.

Automatic standby

The Companion® 20 system automatically goes into the standby state after two hours when there is no audio signal or the volume is turned all the way down. You can disable automatic standby so the system is always on when connected to power.

To disable automatic standby

Lightly press and hold the top of the control pod (approximately six seconds) until you hear two tones that chime from high to low.

To re-enable automatic standby

Lightly press and hold the top of the control pod again until you hear two tones that chime from low to high.

TROUBLESHOOTING

Low volume settings (less than ½ maximum) on your computer or media player reduce its output and can unnecessarily limit the volume of the Companion® 20 system.

Computer volume controls often include:

- External buttons, which may operate independent of the onscreen controls.
- Onscreen controls, provided on the computer.
- · Various media player controls.

Try adjusting one or more of these controls if the sound from the Companion® 20 system is too low.

TROUBLESHOOTING

Problem	What to do
No sound	Make sure the speakers are turned on (the power indicator on the control pod is illuminated).
	Make sure the control pod volume control is not turned fully counterclockwise (minimum).
	 Make sure the computer is plugged in and turned on, mute is turned off, and all volume controls are turned up.
	 Be sure the power pack is securely plugged into the right speaker and into a power outlet or surge protector.
	 Be sure the AC power outlet is working. When using a surge protector or power strip, be sure it is turned on.
The Companion® 20 system sound seems distorted	Decrease the volume of the sound source and increase the Companion® 20 speaker volume using the control pod.

TROUBLESHOOTING

Problem	What to do		
One speaker does not play or sounds distorted	 Make sure the cable from the left speaker is firmly inserted into the Left Speaker connector on the back of the right speaker. Check the balance setting on your sound source. 		
Cannot control the volume using the control pod	Make sure the control pod plug is fully inserted into the connector on the rear of the right speaker. Push the plug in using sufficient force to ensure that it is fully inserted into the connector.		
No sound from headphones			
No sound from the connected device			

Contacting Customer Service

For additional help in solving problems, contact Bose® Customer Service. Refer to the address sheet included in the carton, or visit http://global.Bose.com

MAINTENANCE AND TECHNICAL INFORMATION

Cleaning the system

Wipe the speakers and control pod with a dry cloth.

- Do not use solvents or chemicals.
- Do not allow liquids or objects to enter the rear port of the speakers, the speaker grilles, or any part of the control pod.

If the bottom of the control pod loses its adhesion to the tabletop, use a lint-free cloth, slightly dampened with water, to clean the control pod bottom surface.

Technical Information

Driver complement

Two 2.75 inch (70 mm) high excursion, wide-range transducers

Dimensions (approximate)

Speakers: 8.6"H x 3.5"W x 4.4"D (22.0 cm x 9.0 cm x 15.0 cm)

Control pod: 2.5"D x 1.125"H (6.3 cm x 2.8 cm)

Weight (approximate)

One speaker, unpacked: 2.5 lb (1.1 kg)

Control pod: 0.5 lb (0.2 kg)

LIMITED WARRANTY

This system is covered by a limited warranty. Details of the limited warranty are provided on the Product Registration Card that came with your system. Please fill out the information section on the card and mail it to Bose. Failure to do so, however, will not affect your limited warranty rights.

What you must do to obtain limited warranty service Return the product, with proof of purchase from an authorized Bose dealer, using the following procedures:

- Contact the Bose organization in your country or region (visit http://global.Bose.com for Bose contact information in your country or region) for specific return and shipping instructions.
- **2.** Label and ship the product, freight prepaid, to the address provided by the Bose organization in your country.
- **3.** Place any necessary return authorization number prominently on the outside of the carton. Cartons not bearing a return authorization number where required, will be refused.

このオーナーズガイドは必ずお読みください

オーナーズガイドの指示に注意し、慎重に従ってください。ご購入いただいたシステムを正しくセットアップして操作し、機能を十分にご活用いただくために役立ちます。また、必要な時にすぐにご覧になれるように、大切に保管しておくことをおすすめいたします。

警告:火災や感電を避けるため、製品を雨にあてたり、湿度のある場所で使用しないでください。

警告:水漏れやしぶきがかかるような場所でこの製品を使用しないでください。また、花瓶などの液体が入った物品を製品の上や近くに置かないでください。他の電気製品と同様、システム内に液体が侵入しないように注意してください。液体が浸入すると、故障や火災の原因となることがあります。





正三角形に矢印付き稲妻マークが入った表示は、製品内部に電圧の高い危険 な部分があり、感電の原因となる可能性があることをお客様に警告するものです。



正三角形に感嘆符が入った表示は、製品本体にも表示されている通り、この、取扱説明書の中で、取り扱い上およびメンテナンス上、重要な項目であることをお客様に警告するものです。

警告: 火の付いたろうそくなどの火気を製品の上や近くに置かないでください。

注意:システムまたはアクセサリを改造しないでください。許可なく製品を改造すると、システムの安全性と性能が損なわれるだけではなく、法令遵守の問題が生じ、製品保証が無効となる場合があります。

注意:大きな音量で長時間続けて聞くと、聴力に悪い影響を与えることがあります。 ヘッドホンを長時間使用する場合は、過度な音量を避けるようにしてください。

注意:スピーカーシステムに付属の電源アダプターを使用してください。



This product conforms to all EU Directive requirements as applicable by law. The complete Declaration of Conformity can be found at www.Bose.com/compliance.

注記:

- 製品ラベルは本体下部にあります。
- この製品には付属の電源アダプターを使用してください。
- この製品は室内専用です。屋外、RV 車内、船上で使用するようには設計されていません。また、このような使用環境におけるテストも行われていません。
- 万一の事故や故障に備えるために、電源プラグはよく見えて容易に手が届く位置 にあるコンセントに接続してください。

その他のご注意

その他の注意については、パッケージに同梱の『安全上の重要なご注意』 シートを参照してください(北米のみ)。

iPod は、米国および他の国々におけるApple Inc.の商標です。

©2011 Bose Corporation. 本書のいかなる部分も、書面による事前の許可のない複写、変更、配布、その他の使用は許可されません。

Information about products that generate electrical noise

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, this is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver. Connect the equipment to an outlet on a different circuit than the one to which the receiver is connected.
- Consult the dealer or an experienced technician for help.

Note: Unauthorized modification of the system could void the user's authority to operate this equipment and may void the warranty.

This product complies with the Canadian ICES-003 Class B specifications.

今後のお問い合わせのために

製品に関するお問い合わせ等に必要となりますので、R 側スピーカーの底面に記載されているシリアル番号を、下の欄と保証書に記入してください。

シリアル番号:_			
購入日:			

このガイドとともに、ご購入時の領収証と保証書を保管することをお勧めします。

安全上の留意項目

で使用前に、下記の「留意項目」をよくお読みになり、正しくお使いください。

この「安全上の留意項目」は、製品を安全に正しくお使いいただき、あなたや他の人々への危害 や財産への損害を未然に防止するため、いろいろな絵表示をしています。内容をよく理解してか ら本文をお読みください。

絵表示について



警告 この表示を無視して、誤った取り扱い をすると、人が死亡または重傷を負う 可能性が想定される内容を示します。




この表示を無視して、誤った取り扱い 注意 をすると、人が損傷を負う可能性が想 定される内容および物的損害のみの 発生が想定される内容を示します。

△記号は警告・注意を促す内容があることを告げる ものです。



(左図の場合は分解禁止を意味します)。 配号は行為を強制したり指示する内容を告げるもの です。

▲ 警告





電源ブラグ そのままの状態で使用すると、火災や感雷の原因 となります。すぐに電源スイッチを切り、電源プラグ をコンセントから抜いてください。煙が出なくなるの を確認して、弊社特約店に修理をご依頼ください。



内部に水や異物が入ったときは、すぐに電源スイ ッチを切り、電源プラグを抜く

を抜く

そのままの状態で使用すると、火災や感電の原因 となります。すぐに電源スイッチを切り、電源プラ グをコンセントから抜いて、 弊社特約店に点検を ご依頼ください。特にお子様がいるご家庭ではご 注意ください。



ACアダプターは付属の専用品を使用する 専用ACアダプター以外の使用は、火災や感電の 専用品を使用 原因となります。また、本機の専用アダプターを他

の機器に使うこともお止めください。

▲ 警告



落としたり、キャビネットを破損したときは、 すぐに電源スイッチを切り、電源プラグを抜く ■第プラッ そのままの状態で使用すると、火災や感電の原 因となります。すぐに電源スイッチを切り、電 源プラグをコンセントから抜いて、弊社特約店



雷源コードや雷源プラグが傷んだ場合は交換する 雷源コードや雷源プラグが傷んだ状能(芯線の 交換を依頼 露出、 斯線、変形など) で使用すると、 火災や 感雷の原因となります。弊社特約店に交換をご 依頼ください。



電源コードは付属の専用品を使用する

に点検をご依頼ください。

専用電源コード以外の使用は、火災や感雷の原 ■BB&使用 因となります。また、本機の専用電源コードを他 の機器に使うこともお止めください。

安全上の留意項目

≜警告

電源プラグは、抜き易い位置にあるコンセントに

A ずま行 万一の事故や故障に備えるために、雷源プラグは よく見えて容易に手が届く位置にあるコンセントに 接続してください。



電源プラグは根元まで確実に差し込む

電源プラクは低元まで確実に差し込む 差し込みが不完全な場合、発熱による感電や火災 確実に差す の原因となります。また、ほこりがたまり易くなった り、プラグの金属部分に触れる危険性があります。



交流100ボルトの電源を使用する

海外などで、表示された電源電圧(交流100ボル 南切な需要 ト)以外で使用すると、火災や感雷の原因となり (AC100V) ます。



雷源コードを傷付けない

雷源コードを傷付けたり、加工したり、無理に曲げた り、引っ張ったり、加熱したり、上に重い物を乗せた りしないでください。ケーブルが破損して、火災や感 雷の原因となります。特に、電源プラグ部分やコード が本体から出ている部分はお気を付けください。



タコ足配線をしない

コンセントや配線器具に同時に多数の機器を接続 して雷源を取ると、コードなどが過熱し、火災の原 因となります。



涌風引などから物を入れると火災や感雷の原因 となります。特にお子様にはご注意ください。



涌風孔をふさがない

布をかぶせたり、じゅうたんや布団の上に置いた り、 通気が不十分な狭いスペースに押し込んだり しないでください。本体内部に熱がこもり、火災の 原因となります。

∧ 警告



不安定な場所に設置しない

ぐらついた台の上や傾いた所、振動する所など、不 安定な場所に設置しないでください。落ちたり倒れ、 たりして、けがや事故の原因となります。



機器内部に水をたらしたりかけたり、花びんのよ うに水を満たしたものをそばに置かない

他の電気製品と同様に、機器内部に水分をこぼ したりしないでください。故障や火災の原因とな ります。



風呂、シャワー室など、水のかかる恐れのある場所 には置かない

*場での 機器内部に水が入った場合、火災や感電の原因と 使用禁止 なります。



水の近くまたは湿度の高い場所で使用しない 機器内部に水が入った場合、火災や感雷の原因と

ぬれた手で電源プラグを抜き差ししない ● 感電の原因となります。

火気禁止

機器のそばに、ろうそく等の火がついているもの を置かない

引火して火災の原因となります。



雷が鳴り出したら、本体やケーブル類に触れない 感電の原因となります。



本体のカバーを外したり、分解や改造をしない 火災や感電、けがの原因となります。内部の点検 や修理は、弊社特約店にご依頼ください。



大きな音量で長時間続けて聞くと、聴力に悪い影 響を与えることがあります。特にヘッドホンのご使 用時にはご注意ください。

安全上の留意項目

∧ 注意



高温の場所に置かない

窓を閉めきった自動車の中や直射日光が当たる 場所、執源のそばなど、温度が異常に高くなる場 所に機器を設置・保管しないでください。過熱や 部品の変形などにより、火災や感雷の原因となる ことがあります。



ほこり、油煙、湯気、湿気、高温の場所に置かない ほこり、油煙、湿気の多い場所や、直射日光の当た る場所、直接ライトが当たる場所、高温になる車 の中などには置かないでください。故障の原因と なります。



移動させる場合は、電源コードその他の接続線を 外す

必ず実行 電源コードに無理な力が加わって傷付き、火災や 感電の原因となることがあります。また他の接続線 が引っかかり、けがの原因となることがあります。



電源プラグを抜くときは、電源コードを引っ張らない 電源コードが傷付き、火災や感電の原因となるこ 引っ張り とがあります。必ず電源プラグを持って抜いてくだ さい。



ゴムやビニール製品に本体を長期間接触させない 外装が変質し跡が残ることがあります。



スピーカー開口部に手を入れない

けがの原因となることがあります。特にお子様が まま、いるご家庭ではご注意ください。



雷源を入れる前には音量を最小にする

突然大きな音が出て、聴力障害などの原因となる 音を小さく ことがあります。



長時間音が歪んだ状態で使用しない

スピーカーが発熱し、火災の原因となることがあり ます。

注意



長期間使用しないときは、電源プラグをコンセン

トから抜く 電表プラグ 本機は電源を切った状態でも、常に微弱な電流が 流れています。長期間使用しないときは、安全のた め電源プラグをコンセントから抜いてください。



お手入れのときは電源プラグを抜く

安全のため、お手入れは電源プラグを抜いてから 電源プラグ 行ってください。感電の原因となることがあります。 を抜く



落としたり、ぶつけたり、上に物を乗せたり、水に 浸したりしない



電源プラグにほこりがたまっていないことを確認 する

必ず実行 電源プラグを差してあるコンセント部にほこりがた まると、火災の原因となることがあります。定期的 にコンセント部の掃除をしてください。掃除の際は クリーナーなどの液体がコンセントの周囲にかか らないようにしてください。



表面を変質させる素材を使わない

シンナー、ベンジン、アルコール類などの揮発性の 薬品やクレンザーなどの研磨剤で外装を拭かな いでください。破損、変質、変色、塗料のはがれや 表面に傷を付ける原因となります。

目次

はじめに10
セットアップ11
付属品の確認11
スピーカーとコントロールポッドの配置12
接続14
ケーブルの接続
外部機器の接続
ヘッドホンの接続16
スピーカーシステムの使用17
システムの電源を入れる
音量を調節する
自動スタンバイ18
故障かな?と思ったら19
お問い合わせ先22
お手入れ方法と仕様
システムのお手入れについて23
仕様
保証24


この度は Bose® Companion® 20 マルチメディアスピーカーシステムをお買い上げいただき、誠にありがとうございます。このスピーカーシステムには、次の特長があります。

- デスクトップからお部屋全体まで、2 台のスピーカーだけで豊かで自然なサウンドが広がります。
- どんなコンピューターにもマッチする、流麗でコンパクトなデザインです。
- 音量調節/ミュート機能およびヘッドホンジャック/外部入力端 子が集約されたコントロールポッドが付属しています。
- 独自の TrueSpace® ステレオデジタルプロセッシング回路を搭載し、2 台のスピーカーだけで広がりのある自然なサウンドを実現しています。ライブ感溢れる空間で音楽、ゲーム、ビデオをお楽しみください。
- デジタルシグナルプロセッシング回路は、音量の大小にかかわらず引き締まったクリアなサウンドを再生する、当社独自の機能です。
- 新設計のポートおよびドライバーにより、力強い重低音と豊かな奥行き感を再現しています。

セットアップ


付属品の確認

下図の付属品が全て同梱されていることを確認してください。付属品が不足している場合や損傷などが発見された場合は、お買い上げになった販売店までご連絡ください。箱と梱包材は、輸送用として後日使用する場合のために処分せずに保管しておくことをおすすめします。



^{*}ご使用の国によって形状が異なります。

スピーカーとコントロールポッドの配置



スピーカーは小型でスリムなデザインで、コンピューターの横に 置いても邪魔になりません。より良いサウンド空間を実現するた め、配置の際は以下のガイドラインを参考にしてください。

左右のスピーカーをコンピューターの画面中央から均等な距離 に置きます(スピーカーのLRは背面パネルに記載されています)。

セットアップ

スピーカー同士の距離は 46 cm から 81 cm の間にしてください。


- スピーカーグリルの前面下部を直接さえぎる場所に物を置かないでください。この位置にスピーカードライバーが配置されています。
- コンピューターのモニターに音がさえぎられるほど後方にスピーカーを置かないでください。
- コントロールポッドは操作しやすい場所に置きます。
- スピーカーの前面とコンピューターの画面が真横に並ぶくらい の位置か、画面よりやや手前にスピーカーを置きます。

ケーブルの接続

付属のケーブルと電源コードを、15 ページの図のとおりに接続 します。

注意:電源コードは、他のケーブルの接続を終えた後に接続してください。

- 音声接続ケーブル @ の片側を Right (右)側スピーカー背面の Audio In 端子に差し込みます。
- 2. 音声接続ケーブルのもう片側をコンピューターのヘッドホン 出力またはスピーカー出力(表記と位置は機種によって異なり ます)に差し込みます。
- 3. コントロールポッドのケーブル ⑥ のプラグを Right (右)側スピーカーの Control Pod 端子に差し込みます。
- **4.** 電源アダプターの DC ケーブル ⑥ を Right (右)側スピーカー の DC Power 端子に差し込みます。
- **5.** Left (左)側スピーカーのケーブル **(** を Right (右)側スピーカーの Left Speaker 端子に差し込みます。
- 6. 電源コードのアダプター側プラグ @ を電源アダプターに差し 込んでから、電源コードのプラグを電源コンセントに差し込み ます。



外部機器の接続

コントロールポッドには、3.5 mm プラグ付きケーブル(別売)を使用して iPod や MP3 プレーヤーなどの外部機器を接続できます。外部機器の音声は、コンピューターからの音声と混合されて同時に聞こえます。

外部機器を接続するには:

外部機器に接続された 3.5 mm プラグ付きケーブルをコントロールポッドの外部入力端子に差し込みます。外部機器の音声がコンピューターの音声と混合されないようにするには、コンピューターの音声をミュートします。

ヘッドホンの接続


3.5 mm ステレオミニプラグ付きヘッドホンを接続できます。3.5 mm プラグ付きケーブルをコントロールポッドのヘッドホン端子に差し込みます。Companion® 20 システムにヘッドホンを接続すると、スピーカーからは音声が再生されなくなります。



スピーカーシステムの使用

システムの電源を入れる

コントロールポッドの上面に触れると、スピーカーシステムの電源がオンになり、電源インジケーターが点灯します。コントロールポッドの上面にもう一度触れると、スピーカーシステムの電源がオフになり、電源インジケーターが消灯します。



音量を調節する

コントロールポッドの音量調節つまみ(外側上部のリング)を右に 回すと音量が上がり、左に回すと音量が下がります。

外部機器に音量調節機能が付いている場合:

- **1.** Companion® 20 システムの音量調節つまみをいっぱいまで 左に回し、音量を最小(ゼロ)にセットします。
- **2.** 外部機器の音量を最大より少し下にセットします。 音量を上げても、Companion® 20 システムの音量が最小にセットされているため、スピーカーから音声は再生されません。

注意: 音声が歪む恐れがあるので、外部機器の音量は最大にしないでください。 最大音量の 80% 程度にセットするだけで十分です。

3. Companion® 20 システムの音量調節つまみを右に回し、お好みの音量の位置で止めます。

自動スタンバイ

音声信号を受信しないまま、または音量が最小にセットされたまま 2 時間経過すると、Companion® 20 システムは自動的にスタンバイ状態に移ります。自動スタンバイを無効にして、電源に接続されている間は常にシステムをオンにしておくこともできます。

自動スタンバイを無効にするには:

コントロールポッドの上面(電源インジケーター付近)を、高音と低音のビープ音が聞こえるまでおよそ6秒間軽く長押しします。

自動スタンバイを有効に戻すには:

コントロールポッドの上面(電源インジケーター付近)を、低音と 高音のビープ音が聞こえるまで軽く長押しします。

故障かな?と思ったら

コンピューターや外部機器の音量を下げ過ぎると(最大音量の %未満)、出力が小さくなり過ぎて、Companion® 20 システムの音 量が十分に上げられなくなる場合があります。

コンピューターの音量調節は、以下の方法で行います。

- コンピューター本体に付属のスイッチやボリュームで操作します。
- 画面上でコンピューターの OS から操作します。
- メディアプレーヤーソフトウェアなどの音量調節部を操作します。

Companion® 20 システムの音量が小さすぎる場合は、いずれかの方法による音量調節をお試しください。

トラブル	対処方法
音が出ない	 スピーカーの電源がオンになっている (コントロールポッドの電源インジケーターが点灯している)ことを確認します。 コントロールポッドの音量調節つまみが左にいっぱい(最小)まで回されていないことを確認します。 接続されているコンピューターの電源がオンになっていて、音量が上がっており、ミュートされていないことを確認します。 電源アダプターが Right (右)側スピーカーと電源コンセントまたは避雷器に接続されていることを確認します。 電源コンセントに電源が供給されていることを確認します。避雷器またはテーブルタップを使用している場合は、電源がオンになっていることを確認します。
Companion® 20 シス テムの音声が歪む	外部機器の音量を下げ、Companion® 20 システムのコントロールポッドを使用してスピーカーの音量を上げます。

故障かな?と思ったら

トラブル	対処方法
片側のスピーカーか ら音が聞こえない、 または音が歪む	 Left (左)側スピーカーのケーブルが Right (右)側 スピーカー背面の Left Speaker 端子にしっかり と接続されていることを確認します。 再生機器のバランス設定をチェックします。
コントロールポッド を使用して音量を操 作できない	コントロールポッドのプラグが Right (右)側ス ピーカー背面の端子にしっかりと接続されてい
ヘッドホンから音が 聞こえない	ることを確認します。プラグを差し込む際に は、十分な力を加えて押し込み、プラグを端子
接続された機器から の音が出ない	にしっかり接続してください。

お問い合わせ先

故障および修理のお問い合わせ先

ボーズ株式会社 サービスセンター お客様専用ナビダイヤル 20570-080-023 PHS、IP電話からは、Tel 03-5489-1124へおかけください。 〒206-0035 東京都多摩市唐木田1-53-9 唐木田センタービル

製品等のお問い合わせ先

ボーズ株式会社 ユーザーサポートセンター お客様専用ナビダイヤル 20570-080-021 PHS、IP電話からは、Tel 03-5489-0955へおかけください。

お手入れ方法と仕様

システムのお手入れについて

スピーカーとコントロールポッドを乾いた布で拭きます。

- 溶剤や化学薬品などは使用しないでください。
- スピーカーの背面開口部、スピーカーグリル、コントロールポッドの端子などに液体や異物が入らないようにしてください。

コントロールポッドの底面がデスク上に吸着しなくなったら、糸くずの出ない布を水で湿らせて、コントロールポッドの底面を拭いてください。

仕様

ドライバーユニット

70 mm (2.75 インチ)ハイエクスカーション、ワイドレンジトランスデューサー

※ 本機の詳細寸法につきましては、弊社 Web サイト、ならびに Web サイト上に掲載される仕様書をご参照ください。 保証の内容および条件につきましては、付属の保証書をご覧ください。

Better sound through research®

©2011 Bose Corporation, The Mountain, Framingham, MA 01701-9168 USA AM348605 Rev.00

